

### 2015-16 FORD F350 DRW REAR SWAY BAR CLEARANCE KIT

This kit is for vehicles where the rear sway bar interferes with the carriage bolts and/or the axle straps provided in the HP10247 kit.

- STEP 1** Discard the two 3/8"-16 x 10" carriage bolts and two axle straps provided in the HP10247 kit. Replace them with the items provided in this HP10312 kit.
- STEP 2** Insert two 3/8 -16 x 9" carriage bolts through the slots in the lower bracket. Refer to figure 2A and 2B.
- STEP 3** Place the axle strap under the axle as shown in Figure 2B. Secure the axle strap by using two 3/8" nyloc nuts and two 3/8 flat washers provided in the HP10247 kit.
- NOTE:** Position the carriage bolts and axle straps such that they are not chafing against brake lines or other components before proceeding onto the next step.
- STEP 4** Torque both nyloc nuts to 15 ft-lbs [20 N•m].
- STEP 5** Proceed with the installation of the lower bracket as outlined in Step 5 of the HP10247 manual.

